

COMSOL Day
Orange County



Thursday
May 17, 2018
8:30AM–4:00PM


Microfluidics and Chemical Reaction Engineering

COMSOL Day Orange County, May 17 2018


Mina Sierou

© Copyright 2017 COMSOL. COMSOL, the COMSOL logo, COMSOL Multiphysics, Capture the Concept, COMSOL Desktop, COMSOL Server, and LiveLink are either registered trademarks or trademarks of COMSOL AB. All other trademarks are the property of their respective owners, and COMSOL AB and its subsidiaries and products are not affiliated with, endorsed by, sponsored by, or supported by those trademark owners. For a list of such trademark owners, see www.comsol.com/trademarks.

Mass, Energy, Momentum, and Reactions




Transport Phenomena interfaces



Chemical Reaction Engineering Module
and CFD Module


Transport related Modules in the COMSOL® Product Suite




The Microfluidics Module

Flow Regime Approximations

- Molecular flow
- Rarified flow
- Stokes flow
- Steady laminar flow
- Unsteady laminar flow
- Turbulent flow
- Compressible turbulent flow
- Inviscid flow



Gas flow through a narrow tube into a high vacuum chamber



Compressible turbulent flow in a benchmark model for high Ma flow

Fluid Flow Equations

- Navier-Stokes, continuity, and equation of state

$$\rho \left(\frac{\partial \mathbf{u}}{\partial t} + (\mathbf{u} \cdot \nabla) \mathbf{u} \right) = -\nabla p + \nabla \cdot \left[\mu \left(\nabla \mathbf{u} + (\nabla \mathbf{u})^T - \frac{2}{3} (\nabla \cdot \mathbf{u}) \mathbf{I} \right) \right] + \mathbf{F}$$
$$\frac{\partial \rho}{\partial t} + \nabla \cdot (\rho \mathbf{u}) = 0$$
$$\rho = \rho(p, T)$$

- Estimate the Reynolds number using characteristic scales: L, U, ρ, μ


$$\text{Re} = \frac{\rho UL}{\mu} = \frac{UL}{\nu} \sim \frac{\text{inertial forces}}{\text{viscous forces}}$$

Flow Regimes covered by the Microfluidics Module


- Slip Flow (applicable for small Knudsen number ($0.01 < Kn < 0.1$)
 - Viscous flow in the bulk
 - Velocity slip at the boundaries
- Stokes flow (low Re ($\ll 1$)
 - The contribution of advective inertial forces can be neglected
- Laminar flow (intermediate Re (~ 1 -2000))
 - Steady or Unsteady flow

Physics Features for Laminar Flow


Domain conditions:




Point conditions:



Boundary conditions:




Edge conditions:




Laminar Inflow and Laminar Outflow

- Defines a laminar velocity profile for inlets/outlets with boundaries of any shape
 - Internally, a Navier-Stokes equation (D-1) is solved and projected on the boundary
 - Corresponds to a virtual domain that is attached upstream to the inlet




$$L_{entr} \gg 0.06 Re * D$$

☐ Constrain outer edges to zero



Velocity profile is defined
by adjacent boundaries of
real domain

☒ Constrain outer edges to zero



Force laminar velocity profile
to zero at adjacent
boundaries of real domain

Boundary Condition

Laminar inflow

Laminar Inflow

☒ Average velocity

☐ Flow rate

☐ Entrance pressure

Average velocity:

U_{av} 0 m/s


Entrance length:

L_{entr} 1 m


☐ Constrain outer edges to zero

Multiphase Flow, Categorization

- Separated multiphase flow models:
 - For bubbles, droplets, phase boundaries, or particles that are relatively few and of the order of magnitude of the model domain
 - For multiphase flow in microfluidics
 - For free surfaces in otherwise single-phase fluids that are also in macroscopic systems




- Dispersed multiphase flow models (part of CFD Module only):
 - For bubbly flows with a large number of relatively small bubbles
 - For emulsions and aerosols
 - For large numbers of solid particles in fluids
 - For macroscopic multiphase flow (almost always required)




Multiphase Flow, Categorization

- Separated multiphase flow models




- Dispersed multiphase flow models




Multiphase Flow, Separated Flows

- Tracks the exact surface location using the level set or phase field models, or by using moving mesh
- Accurate modeling of surface-tension effects
- Includes a surface-tension coefficient library
- Level set and phase field can handle topology changes while moving mesh cannot
- Moving mesh can be very accurate and it is also simple to add forces and other boundary conditions at the phase boundary

Moving mesh






Phase field



Electrokinetic Flow


- Utilizes electric fields to move fluids
- Primarily used to pump or mix fluids
- Based on two main phenomena
 - Electroosmosis
 - Explicit modeling of electric double layers on small length scales
 - On larger scales, the electroosmotic mobility can be specified as part of a slip boundary condition
 - Electrophoresis and dielectrophoresis



Chemical Reaction Engineering Module

The Chemical Reaction Engineering Module


- Chemical species transport and reactions
 - Concentrated solutions (Maxwell-Stefan), dusty gas, dilute solutions
 - Free and porous media
- Reaction kinetics
 - Mass action law
 - Type in analytical expressions of concentrations
 - Homogeneous and heterogeneous reactions
- Fluid flow
 - Laminar flow and porous media flow
- Heat transfer and heat of reactions
 - Conduction, convection and radiation (surface to ambient)



The transport and reaction interfaces in the Chemical Reaction Engineering Module


Transport in Diluted Solutions

- Solute interacts only with solvent
- Solution density equals solvent density
- Chem. Reaction Engineering Module:
 - Fick's law
 - Knudsen and dusty gas





Transport in Multicomponent Solutions

- All species interact with each other
- Solution density is the sum of all species density
- Chem. Reaction Engineering Module:
 - Maxwell-Stefan
 - Mixture averaged
 - Knudsen and dusty gas





Reaction Model

- Steam reforming:



- Kinetics through mass action law or user defined

- Simplified input:




- Last step: thermodynamic properties

Perfectly Mixed System

2. The material balances for the species are automatically generated as you type in the chemical equations.

Models for batch, semibatch, continuous stirred tank reactors, and plug-flow reactors are predefined.



1. Just type in the chemical reactions.

3. The kinetics are automatically formulated according to the mass-action law. If needed, you can replace the rate law with your own expressions.

4. Automatic units of rate constants, depending on kinetics expressions.

Thermodynamic Properties

1. Add a *Property Package* node.

At this stage, the thermodynamic property package is decoupled from the species list in the *Reaction Engineering* node.

The screenshot shows the COMSOL Model Builder interface. On the left, the 'Model Builder' tree has 'Property Package 1 (pp1)' selected under the 'Thermodynamics' node. On the right, the 'Settings' pane for 'Property Package 1' is displayed. It includes a 'Label' field set to 'Property Package 1', a 'Package Information' section, a 'Species' table with 5 rows, a 'Phases' table with 2 rows, and a 'Thermodynamic Model' dropdown set to 'Ideal gas'.

Name	CAS	Formula	Database
methane	74-82-8	CH4	COMSOL
water	7732-18-5	H2O	COMSOL
carbon dioxide	124-38-9	CO2	COMSOL
carbon mono...	630-08-0	CO	COMSOL
hydrogen	1333-74-0	H2	COMSOL

Name	State
Gas	Vapor

Thermodynamic model: Ideal gas

2. Add compounds from the database.

3. Select phase.

4. Select thermodynamic model.

Thermodynamic Properties, Species Matching

1. Select the *Reaction Engineering* node.

The thermodynamic property package is now coupled to the species list in the *Reaction Engineering* node.

The screenshot displays the COMSOL Model Builder interface. On the left, the 'Model Builder' tree shows the hierarchy: 'steam_reforming.mph (root)' > 'Global Definitions' > 'Parameters' > 'Thermodynamics' > 'Property Package 1 (pp1)' > 'Materials' > 'Component 1 (comp1)' > 'Definitions' > 'Reaction Engineering (re)'. The 'Reaction Engineering (re)' node is selected. On the right, the 'Settings' panel for 'Reaction Engineering' is shown. It includes fields for 'Label' (Reaction Engineering) and 'Name' (re). Below these are expandable sections: 'Equation', 'Reactor', 'Energy Balance', 'Calculate Transport Properties', 'Mixture Properties', 'Species Matching', 'Discretization', and 'Mass Balance'. The 'Species Matching' section is expanded, showing a table with columns 'Species' and 'From Thermodynamics'. The table lists five species (a, b, c, d, e) and their corresponding thermodynamic packages (CH4, H2O, H2, CO, CO2).

Species	From Thermodynamics
a	CH4
b	H2O
c	H2
d	CO
e	CO2

2. Activate energy balance.

3. Match species.


Space-Dependent Model

- Reactor model:
 - Tubular reactor with laminar flow



Generate Space-Dependent Model


1. Add the *Generate Space-Dependent Model* node.



2. Select space dimension.


3. Select type of transport.

Demo: Thermal Decomposition




Geometry

- 3D geometry can be approximated with 2D cross section



Thermal Decomposition

- Thermal Decomposition:



(Fragments (F)
concentration is assumed
constant)

- Reaction Rate:

$$\text{rate} = kc_A$$

- Rate constant:

$$k = A \exp\left(-\frac{E}{R_g T}\right)$$

- Heat of reaction:

$$Q = -\text{rate} \cdot H$$

Demo: Modeling Band Dispersion in a Curved Microchannel




Background

- The curved microchannel geometry induces dispersion in the analyte band as the later traverses through the geometric turn.
- The turn-induced dispersion could affect the detection downstream. One of the proposed solutions is geometric optimization. By altering the microchannel geometry, the turn-induced dispersion could be minimized.
- This model studies the band dispersion (of neutral species) in an Electroosmotic flow (EOF) – different geometry set-ups can be studied and the design can also be optimized (would require Optimization Module)

Understanding the Turn-Induced Dispersion

- One of the most obvious reasons for the dispersion is difference in the inner and outer path lengths, also known as Racetrack effect.
- The other important reason is the difference in solute velocity in the curved section, which arises due to difference in potential gradient.




Solute traverses faster along the inner edge due to higher electric field (proportional to velocity)

Equipotential Lines and Velocity Surface plot

Modeling

- The Electric Currents interface is used to model the electric field in the microchannel. The Creeping Flow interface is used to model the fluid flow using the simplified Electroosmotic velocity boundary condition. The Transport of Diluted Species interface is used to model the mass transport.
- The present model is developed for neutral species transport in EOF however the same idea is applicable for electrophoresis problems as well. This is because both fluxes, convective and migrational, vary linearly with concentration and electric field.


Results



Concentration surface plot for original and optimized geometry at different times

Demo

Dielectrophoretic Separation of Platelets from Red Blood Cells




Dielectrophoresis

- Dielectrophoresis is the movement of particles in non-uniform electric fields due to the interactions of the particles' induced dipoles with the field gradients
- Dielectrophoretic force: $\mathbf{F}_{\text{ext}} = 2\pi r_p^3 \epsilon_0 \text{real}(\epsilon_f^*) \text{real}\left(\frac{\epsilon_p^* - \epsilon_f^*}{\epsilon_p^* + 2\epsilon_f^*}\right) \nabla |\mathbf{E}_{\text{rms}}|^2$
- Shell feature can be added for particles with thin dielectric shells:

$$\epsilon_{\text{eq}}^* = \epsilon_s^* \frac{\left(\frac{r_0}{r_i}\right)^3 + 2\left(\frac{\epsilon_p^* - \epsilon_s^*}{\epsilon_p^* + 2\epsilon_s^*}\right)}{\left(\frac{r_0}{r_i}\right)^3 - \left(\frac{\epsilon_p^* - \epsilon_s^*}{\epsilon_p^* + 2\epsilon_s^*}\right)}$$


Dielectrophoretic separation

- Geometry and boundary conditions




Results


Electric potential distribution



Particle trajectories without dielectrophoresis



Particle trajectories with dielectrophoresis
(Red: Red Blood Cells, Blue: Platelets)



Q & A

COMSOL Resources on the Web




Products Video Gallery We

COMSOL BLOG

Evaluate Your 3D Inductor Design with COMSOL Multiphysics

Scott Smith | April 19, 2016




Inductive devices exhibit a range of electromagnetic effects that have to be taken into account when they are utilized as part of any application. With the tools provided by the AC/DC Module in COMSOL Multiphysics, you can model and design an inductor in a straightforward yet accurate way, as well as calculate the device characteristics your application demands.



Products Video Gallery Webinars Support Contact

VIDEO GALLERY



search




Featured Videos

Sort by:



COMSOL CONFERENCE 2018 BOSTON



SAVE THE DATE

October 3–5

 COMSOL

